




INSTRUCTION MANUAL

Original instructions for

IMMERSION BLENDER

(HAND MIXER)

08400100/ 08400200



Keep these instructions with the appliance.

You should read this user manual carefully before using the appliance.

Dear Customer,

Thank you for purchasing this appliance. Please take a few minutes before starting operation of the appliance and read the following operating instructions.

1. Intended use

- 1.1** This machine is designed for food processing in restaurants, canteens and similar catering establishments.
- 1.2** The machine is not intended to process for meat which has bone, tough skin, shells or fish scales. Neither use this machine to cut vegetable or fruit with nut or tough skin. Otherwise, it might lead to damage of the machine, property or personal injury.
- 1.3** The machine is intended for commercial and indoor use by trained and skilled personnel familiar with these instructions.

The machine body is built in PA66+GF30% and stainless steel, aluminum alloy for easy cleaning and maintenance. It has safety features compliant with the applicable safety Directives.

2 Safety regulations

2.1 Safety regulations

- 2.1.1** This appliance is intended for commercial use only and must not be used for household use.
- 2.1.2** The appliance must only be used for the purpose for which it was intended and designed. The manufacturer is not liable for any damage caused by incorrect operation and improper use.
- 2.1.3** Keep the appliance and electrical plug away from water and any other liquids. In the event that the appliance should fall into water, immediately remove plug from the socket and do not use until the appliance has been checked by a certified technician. Failure to follow these instructions could cause a risk to lives.

2.1.4 Never attempt to open the casing of the appliance yourself.

2.1.5 Do not insert any objects in the casing of the appliance.

1.1.6 Do not touch the plug with wet or damp hands.

2.1.7 Danger of electric shock! Do not attempt to repair the appliance yourself. In case of malfunctions, repairs are to be conducted by qualified personnel only.

2.1.8 Never use a damaged appliance! Disconnect the appliance from the electrical outlet and contact the retailer if it is damaged.

2.1.9 Do not immerse the electrical parts of the appliance in water or other liquids. Never hold the appliance under running water.

2.1.10 Regularly check the power plug and cord for any damage. If the power plug or power cord is damaged, it must be replaced by a service agent or similarly qualified persons in order to avoid danger or injury.

2.1.11 Make sure the cord does not come in contact with sharp or hot objects and keep it away from open fire. To pull the plug out of the socket, always pull on the plug and not on the cord.

2.1.12 Ensure that the cord (or extension cord) is positioned so that it will not cause a trip hazard.

2.1.13 Always keep an eye on the appliance when in use.

2.1.14 As long as the plug is in the socket the appliance is connected to the power source.

2.1.15 Turn off the appliance before pulling the plug out of the socket.

2.1.16 Never carry the appliance by the cord.

2.1.17 Do not use any extra devices that are not supplied along with the appliance.

2.1.18 Only connect the appliance to an electrical outlet with the voltage and frequency mentioned on the appliance label.

2.1.19 Connect the power plug to an easily accessible electrical outlet so that in case of emergency the appliance can be unplugged immediately. To completely switch off the appliance pull the power plug out of the electrical outlet.

2.1.20 Always turn the appliance off before disconnecting the plug.

2.1.21 Never use accessories other than those recommended by the

manufacturer. Failure to do so could pose a safety risk to the user and could damage the appliance. Only use original parts and accessories.

2.1.22 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.

2.1.23 This appliance must not be used by children under any circumstances.

2.1.24 Keep the appliance and its cord out of reach of children.

2.1.25 Always disconnect the appliance from the mains if it is left unattended or is not in use, and before assembly, disassembly or cleaning.

2.1.26 Never leave the appliance unattended during use.

2.2 Special Safety Regulations

2.2.1 The appliance is intended for commercial and indoor use by trained and skilled personnel familiar with these instructions.

2.2.2 This machine is designed for food processing in restaurants, canteens and similar catering establishments.

2.2.3 Any other use might lead to damage to the appliance or personal injury.

2.2.4 Do not place the appliance on a heating object (gasoline, electric, charcoal cooker, etc.) Keep the appliance away from any hot surfaces and open flames. Always operate the appliance on a level, stable, clean, heat-resistant and dry surface.

2.2.5 **Danger** of injury! Care is needed when operating or cleaning. Wear protective gloves (not supplied) if necessary.

2.2.6 **Caution!** Securely route the power cord if necessary, in order to prevent unintentional tripping over and falling.

2.2.7 Do not use the appliance before it is properly assembled.

2.2.8 This appliance is not intended to be operated by means of an external timer or separate remote-control system.

2.2.9 Never bypass any safety interlocks on the appliance.


2.2.10 **WARNING:** ALWAYS switch off the appliance and unplug from electrical power supply before cleaning, maintenance or storage.

- 2.2.11 WARNING:** ALWAYS keep hands, long hair and clothing away from the moving parts.
- 2.2.12 WARNING:** Take great care when handling the cutting blade. Wear protective gloves (not supplied) if necessary.
- 2.2.13** Allow at least 15cm spacing around the appliance for ventilation purpose during use.
- 2.2.14** Do not wash the appliance with water or waterjet. Washing with water can cause leakage and increase the risk of electric shock. No parts are dishwasher safe.

3

PRODUCT DESCRIPTION

3.1 Parts of description



3.2 MAIN TECHNICAL PARAMETERS

Model	Voltage Supply	Power	Speed (rpm)	Body N.W.
08400100	100-120V~ 60Hz, 220-240V~ 50/60Hz	220W	4000~18000	1.0 kg
08400200		250W	4000~18000	1.0 kg

4 INTRODUCTION

4.1 Preparation for first use

- 4.1.1** Check to make sure the appliance is undamaged. In case of any damage, contact your supplier immediately and do NOT use the appliance.
- 4.1.2** Remove all the packing material and protection film (if applicable). Keep the packaging for future storage.
- 4.1.3** Clean the appliance, see: **4.5 Cleaning**.
- 4.1.4** Place the food bowl or other container on a level and steady surface, unless mentioned otherwise. It is forbidden to put the machine above different objects from the working ground used in the food field of height included between 900 – 1100mm from the trampling level.
- 4.1.5** Position the appliance in such a way that the plug is accessible at all times.
- 4.1.6** Make sure the power outlet ratings correspond to the specifications printed on the rating plate.
- 4.1.7** Make sure that the machine is connected to a grounding system if it's needed.
- 4.1.8** Even if safety systems are installed on the machine, prevent approaching moving parts with hands and do not touch the machine with wet or damp hands.
- 4.1.9** **Warning!** When the whisk is used, make sure to start appliance with low speed.
- 4.1.10** **Warning!** It is forbidden the use of the whisk in the machines with fixed speed.

- 4.1.11 Disconnect the machine's socket from the electric before carrying out any cleaning or maintenance operations.
- 4.1.12 Do not clean with high-pressure water jet.
- 4.1.13 It is strongly recommended that the operator contact the after sales center if there is any problem or malfunction occurred. Please do not dismantle the machine or in place of unauthorized parts.

Warning: This machine must be properly immersed and used in water. To avoid overheating or damage, DO NOT allow it to run in air for more than 10 seconds.

4.2 The manufacturer will be not responsible for following cases:

- 4.2.1 If the machine is tampered with or safety functions are installed by non-authorized staff.
- 4.2.2 If the components are replaced by unauthorized parts.
- 4.2.3 If the instruction in this manual is not carefully followed.
- 4.2.4 If the machine surfaces are treated with unsuitable substance or solvent.

4.3 INSTALLATION

4.3.1 Packing and unpacking

- 4.3.1.1 Remove all packaging materials. Keep the packaging for future storage.
- 4.3.1.2 After unpacking all accessories, read the manual carefully before installation.
- 4.3.1.3 Make sure the delivery contents are complete and free of any damage. If you find that parts are missing or show damage, do not use the appliance but contact your dealer.

4.3.2 STARTING AND STOPPING THE BLENDER

- 4.3.2.1 Insert the blender tube into the appliance.
- 4.3.2.2 Connect the appliance to the power supply.
- 4.3.2.3 Press down the Switch button (NO.1),
the appliance starts running, and keeps

running if you don't release pressing.

The machine will stop when you release the button (NO.1).

4.3.2.4 Adjust the speed with speed control buttons (No.3 or No.4)


4.3.3 ADJUST SPEED

Follow above steps 4.3.2.1 to 4.3.2.3, then:

Change the speed of the motor by pressing the

Speed Button, from minimum speed 1 to maximum

speed 8. Press “+” button (No.2) to speed up, while press “-” button (No.3) to speed down. The Speed Display (No.4) always show the speed you selected.




4.3.4 Working position:

4.3.4.1 Blender function: For better control, we recommend that you hold the blender by the handle and the bottom of the motor unit. Furthermore, we recommend that you tilt the blender at a slight angle to prevent the bell from touching the bottom of the container. Always make sure that the bell is sufficiently immersed to avoid splashing and that the air vents of the motor unit does not come into contact with any liquid. For optimum efficiency, two thirds of the tube should be immersed in preparation.

4.4 ASSEMBLING / DISMANTLING:

The assembly / disassembly operations of every device of the appliance are performed with the appliance stop and with the plug disconnected from the socket.



Assembly

1. Align and insert the coupling (4) of the tube (3) in the clutch (2) of the machine body (1).
2. Screw the tube (3) up to fasten it firmly to the machine body (1).

The disassembly activities perform following in a backgrounds way the assembly phases previously described.

4.5 CLEANING

As a precaution, always unplug your appliance before cleaning it.

- 4.5.1 After using the immersion blender and whisk in a hot preparation, cool the bottom of the tube in cold water before dismantling the bell from the tube. After completion of preparation, clean immediately to prevent food from sticking to surfaces.
- 4.5.2 Never put the motor unit and its handle in water, clean them with a damp cloth or a sponge.
- 4.5.3 Blender tube and bell cleaning: Place the tube and bell into a suitable container with water and switch on for a few seconds to clean the bell and tube.

WARNING: Always dry the blades thoroughly after cleaning to avoid spotting.

- 4.5.4 Never immerse the whisk holder in water, clean it with a slightly damp cloth or sponge.

- 4.5.5** It is vital to clean it thoroughly between each job using a detergent or disinfectant, but never use pure bleach. For plastic parts, do not use detergents that are too alkaline.

Warning 1: The blender tubes are not suitable for the dishwasher!

Warning 2: Blender tubes cannot be immersed thoroughly in water!

4.6 Storage


- 4.6.1** Before reassembling, make sure that all parts are dry. Before storing, remove all residues from the appliance and attachments, disconnect it from the supply and clean the appliance and its accessories thoroughly.
- 4.6.2** Store the appliance in a dry, protected environment at room temperature and out of the reach of children.
- 4.6.3** We recommend to put the appliance and attachments onto "wall hanger" for dry and safe storage.

4.7 Troubleshooting


- 4.7.1** If it is due to a power cut if the appliance had been unplugged, press down the Off button (No.2), check the power supply and restart the appliance.
- 4.7.2** If it is due to overheating of the machine, press down the Off button (No.2), and then unplug the appliance, wait a few minutes for the motor to cool down and the thermal safety mechanism to be reset, and then restart the appliance.
- 4.7.3** If you cannot locate the cause of the problem: press down the Off button (No.2), unplug the appliance, check below:
- 1.** the plug.
 - 2.** that the blades are free to rotate in the bell, be careful the blade is very sharp.
 - 3.** that state of the power cord.
 - 4.** the drive shaft is free to rotate. To do this, remove the bell and test the rotation of the end of drive shaft manually.

If a malfunction occurs which is not on our list of possible faults, consult your retailer or return the appliance to the after-sales services.

5 Circuit diagram



6 Exploded view and spare parts lists



No.	English Name
1	Switch sheath
2	Membrane switch
3	Speed control panel
4	Power cord
5	Cable sheath
6	Upper and lower housing
7	Pressing board
8	One set of screw plungers
9	PCB control board
10	Motor
11	Spline sleeve
12	Pin
13	Spline
14	Steel ring
15	Seal ring
16	Aluminum head housing
17	Output axis
18	S/S tube
19	Knife protector
20	Copper sheath
21	Seal ring 2
22	Seat of copper sheath
23	Oil seal
24	Blade