Powder Filling Machine

MODEL: SBF-100-V1, SBF-100-V2



AWARNING

- 1. Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating.
- 2. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

GENERAL SAFETY RULES

Important reminder

- 1.Before use, please carefully read the product manual and ensure that you understand and comply with all safety warnings and usage precautions.
- 2. Do not use this product for other non-designated purposes to avoid unexpected risks.
- 3. This product is only applicable to users within the specified age group and scope of application. Please strictly comply with relevant age restrictions and warnings.
- 4. If there are any abnormalities in the product, please stop using it immediately and contact the after-sales service center for consultation or to arrange for repair.

Environmental requirements for use

- 1. Please use in a dry and well-ventilated environment to avoid extreme environmental conditions such as water activation, high temperature, high humidity, and extremely low temperature.
- 2. Avoid direct sunlight or contact with fire sources to prevent product damage or fire.
- 3. Please ensure a stable usage environment and prevent the product from being hit or dropped to avoid damage.

Safety Operation Guidelines

- 1. Please use a suitable power supply and voltage, and do not use damaged power cords or plugs.
- 2. When using this product, do not short-circuit circuits or connect mismatched devices to avoid risks such as electric shock and fire.

- 3. When foreign objects are found on the surface of the product, please immediately stop using and remove the foreign objects before continuing to use.
- 4. When using this product continuously for a long time, please rest in good time to avoid excessive fatigue.
- 5. Do not plug or unplug the power plug with wet hands to avoid the risk of electric shock.

Maintenance and upkeep

- 1. Regularly maintain and clean the product. Before cleaning, please disconnect the power supply and wipe it with a dry cloth. Be careful not to use alcohol, acid or alkali solutions, etc
- 2. When the product is not in use for a long time, please disconnect the power supply promptly to save energy and extend the product's lifespan.
- 3. Do not disassemble the product or replace components on your own. If you encounter any malfunctions, please contact the after-sales service center

Emergency handling measures


- 1. When there are abnormal situations or accidents with the product, please stop using it as soon as possible.
- If overheating, smoking, or abnormal sound are found, please immediately cut off the power supply and contact the after-sales service center.
- 2. If the product involves an emergency situation that may harm personal safety, please call the emergency rescue number in a timely manner.

SAVE THESE INSTRUCTIONS

MODEL AND PARAMETERS

Model	SBF-100-V1	SBF-100-V2	
Suitable Particle	Granular and powdered materials. Not floury materials,smooth surface particles		
Particle Size	Φ<5mm	Φ<5mm	
Filling Range	1-99.9g	1-99.9g	
Voltage	AC120V 60Hz	AC230V 50Hz	
Power(Max.)	550W	550W	

STRUCTURE DIAGRAM



- 1. Reel 2.Fixed Mount 3. Outlet 4. Film Sealing Machine
- 5. Handle 6.Power Switch 7. control panel
- 8. Powder Filling Machine 9. Hopper


COMPONENTS


Model	SBF-100-V1	SBF-100-V2
Powder Filling Machine	×1	×1
Film Sealing Machine	×1	×1
Open-end Wrench (10MM)	×1	×1
Open-end Wrench (14MM)	×1	×1
Power Cord	×2	×2
Signal Wire	×1	×1
User Manual	×2	×2
Fixed Mount	×1	×1
Stainless Steel Tube	×2	×2
Galvanized Tube	×1	×1
Baffle	×2	×2
Stop Collar	×3	×3
Flat Gasket	×1	×1
Spring	×1	×1


OPERATING INSTRUCTIONS

1.Remove the installed screws.Install the fixed mount and lock it with the screws you just removed as shown. 2.Install the galvanized tubes and the stainless steel tubes on the square tubes successively as shown. Galvanized Tube Stainless Steel Tube


3.Install first stop collar. Then install the baffle(A), gasket(B) and spring(C) in turn. Install the second stop collar and properly press the spring. Then install the film roll and the second baffle, and lock it with the third stop collar as shown. Δ







9. Align the two machine ports and connect them with signal wire as shown. duct ass embly completed.



- 1. Upper temperature: Display vertical sealing temperature.
- 2. Lower temperature: Display the notch sealing temperature.
- 3. Length: Displays set bag length.
- 4. Quantity: Display the number of sealed bags.
- 5. Upper temperature adjust"+":Increase the vertical sealing temperature.
- 6. Upper temperature adjust"-":Lower the vertical sealing temperature.
- 7. Stop:Stop the machine.(Red light when it stops)
- 8. Run: When the temperature reaches, the light turns green.
- 9. Length adjust"+":Increase the bag length
- 10.Length adjust"-":Shorten the bag length
- 11.Lower temperature adjust"+":Increase the notch sealing temperature.
- 12.Lower temperature adjust"-":Lower the notch sealing temperature.
- 13.Jog:Manual test key. Set:To set internal functions, hold down.
- 14.Zero/Quantity
- 15.Pull:Hand stretch bag.
- 16.Cut:Hand bag cutting.

The operating instructions

- 1. Put the two machines in a stable position with the feed ports in line.
- 2. Plug in the power cable and turn on the power switch.
- 3. Set the working temperature of sealing bag.(It is recommended to set the temperature between 100 and 140 degrees Celsius.It is related to the film material.)
- 4. When the temperature reaches the set value, the first test machine makes 3 to 5 empty bags.
- 5. Turn on both machines to automatically fill and seal bags.


Tips:The bag length can be set according to the need to fill the required materials.

MAINTENANCE

- 1.The user shall select a quantitative filling machine of a suitable range according to the said products.
- 2. The machine contains a precision electronic scale, it is forbidden to be overweight.
- 3. When in use, please keep the machine level and stable to avoid big vibrations or impact; otherwise, it may cause damage.
- 4. After use, please clean the material and keep the machine clean
- 5. When the machine is not in use, please empty the materials and store it in a ventilated and dry place.
- 6. Please clean the product and the filter in time after each use.
- 7. Always keep the product outside clean.

Please store the product in a dry and ventilated place.

If the fuse is damaged, replace it as shown.



TROUBLESHOOTING

Problem	Possible Cause	Possible Solution	
The product doesn't work	The power cord is not	Reconnect the power	
	plugged in properly	cord	
	Fuse failure	Replace the fuse	
	The film roll is upside	Reinstall the film roll	
Bag-making stopped	down.		
	The signal wire is not	Reinsert the signal cable	
	plugged in		
	The handle didn't go	The handle rotates back	
	back.	into place.	
	The film roll is not	Film roll re-fixed	
	secured		
Bag sealing is not good	Sealing temperature is	Set the appropriate	
	too low.		
	Sealing temperature is	temperature as recommended	
	too high.	recommended	

- 1	4	-
-----	---	---